



# Sony Cyber-Shot DSC-W120 LCD Screen Replacement

This guide will explain how to remove your camera's LCD display.

Written By: Christopher



## INTRODUCTION

If the LCD display unit of your Sony Cyber-Shot DSC-W120 is damaged, this guide will walk you through the process of locating and removing it.

---



### TOOLS:


- [Phillips #00 Screwdriver](#) (1)
  - [iFixit Opening Tools](#) (1)
-

## Step 1 — LCD Screen



- Unscrew the screws on the right side of the camera.


## Step 2



- With a plastic opening tool, gently lift and remove the silver piece on the right side of the camera.




### Step 3




- Use a plastic opening tool to carefully lift and remove the front case.

### Step 4




- Gently pry the silver piece on the left side of the camera off with a plastic opening tool.

## Step 5



- Unscrew the three screws on the bottom of the camera.

## Step 6



- Use a plastic opening tool to lift and remove the back case.





## Step 7



- Remove the screw located above the mode dial.

## Step 8



- Lift the LCD display from the rest of the camera.
- Use tweezers to carefully separate the connecting tape.

To reassemble your device, follow these instructions in reverse order.

